

Peterbilt 2023 Warranty Reference Guide

Part Description	Emissions Base Warranty	Standard Class B Vehicle (Basic Vehicle)	Standard Class 6/7 Vehicle (Basic Vehicle)	Battery Electric (Basic Vehicle)	Standard MX Engine (Base Engine)	Standard Major Engine Components	Standard Major Vehicle Components	Standard Severe Service	Standard PACCAR Alternator & Starter	Standard PACCAR Front Axles	Standard Non-PACCAR Front Axles	Standard PACCAR Clutch	Standard PACCAR Transmission	Standard Non-PACCAR	Standard Frame, Rails, Gussets, Crossmembers, Cab/Hood/Sleeper Corrosion or Perforation Caused by Corrosion	Standard Paint	Extended Warranty: MX Premium	Extended Warranty: MX PP1	Extended Warranty: MX PP2	Extended Warranty: MX Aftertreatment	Extended Warranty: Basic Vehicle	Extended Warranty: Battery Electric Basic Vehicle	Extended Warranty: Major Engine Components	Extended Warranty: HVAC	Extended Warranty: Electrical Wiring Harness Class 8	Extended Warranty: Electrical Wiring Harness Class 6/7	Extended Warranty: PACCAR Clutch	Extended Warranty: PACCAR Transmission	Red Oval Vehicle	Red Oval Engine	Red Oval 90 Day									
Cylinder Block - Piston Liners, Rings					X												X	X	X											X	X	X								
Cylinder Head - Cap Screws					X												X	X	X												X	X	X							
Cylinder Head - Casting Inlet/Injector Cup					X	X											X	X	X												X	X	X							
Cylinder Head - Expansion Plugs																	X	X	X												X	X	X							
Cylinder Head - Gasket																	X	X	X												X	X	X							
De-Aeration Lines (Turbo, BPV, EGR)					X												X	X	X												X	X	X							
Deck Plate Lamp																																	X	X						
Decomposition Pipe					X																													X	X					
Diesel Exhaust Fluid (DEF) - Air Supply Pressure, Protection Valve					X																														X	X				
Diesel Exhaust Fluid (DEF) - Coolant Valve					X																															X	X			
Diesel Exhaust Fluid (DEF) - Dosing ECU, Wiring Harness, Connectors					X																																X	X		
Diesel Exhaust Fluid (DEF) - Dosing Filter					X																																X	X		
Diesel Exhaust Fluid (DEF) - Dosing Valve [Injector]					X																																X	X		
Diesel Exhaust Fluid (DEF) - Engine Coolant Lines					X																																X	X		
Diesel Exhaust Fluid (DEF) - Heater Control Lines (Tubing)					X																																	X	X	
Diesel Exhaust Fluid (DEF) - Heater Control Relay					X																																	X	X	
Diesel Exhaust Fluid (DEF) - Heating Elements					X																																	X	X	
Diesel Exhaust Fluid (DEF) - Heating Fittings (3 on Supply Module)					X																																	X	X	
Diesel Exhaust Fluid (DEF) - Lamp					X																																	X	X	
Diesel Exhaust Fluid (DEF) - Level / Quality Sensor					X																																		X	X
Diesel Exhaust Fluid (DEF) - Pump Module					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																		X	X
Diesel Exhaust Fluid (DEF) - Tank Assembly					X																																			

Peterbilt 2023 Warranty Reference Guide

Part Description	Emissions Base Warranty	Standard Class 8 Vehicle (Basic Vehicle)	Standard Class 6/7 Vehicle (Basic Vehicle)	Battery Electric (Basic Vehicle)	Standard MX Engine (Base Engine)	Standard Major Engine Components	Standard Major Vehicle Components	Standard Severe Service	Standard PACCAR Alternator & Starter	Standard PACCAR Front Axles	Standard Non-PACCAR Front Axles	Standard PACCAR Clutch	Standard PACCAR Transmission	Standard Non-PACCAR	Standard Frame, Rails, Gussets, Crossmembers, Cab/Hood/Sleeper Corrosion or Perforation Caused by Corrosion	Standard Paint	Extended Warranty: MX Premium	Extended Warranty: MX PP1	Extended Warranty: MX PP2	Extended Warranty: MX Aftertreatment	Extended Warranty: Basic Vehicle	Extended Warranty: Battery Electric Basic Vehicle	Extended Warranty: Major Engine Components	Extended Warranty: HVAC	Extended Warranty: Electrical Wiring Harness Class 8	Extended Warranty: Electrical Wiring Harness Class 6/7	Extended Warranty: PACCAR Clutch	Extended Warranty: PACCAR Transmission	Red Oval Vehicle	Red Oval Engine	Red Oval 90 Day	
Suspension - Dowl Pin		X	X	X				X												X	X							X	X	X		
Suspension - Height Control Valve		X	X	X				X												X	X								X	X	X	
Suspension - Height Control Valve Bracket		X	X	X				X												X	X								X	X	X	
Suspension - Height Control Valve Linage		X	X	X				X												X	X								X	X	X	
Suspension - Sleeper		X	X	X				X												X	X								X	X	X	
Suspension - Spring, Air		X	X	X				X												X	X								X	X	X	
Suspension - Spring, Bracket		X	X	X				X												X	X								X	X	X	
Suspension - Spring, Leaf		X	X	X				X												X	X								X	X	X	
Suspension - Spring, Pin		X	X	X				X												X	X								X	X	X	
Suspension - Spring, Saddles		X	X	X				X												X	X								X	X	X	
Suspension - Spring, Shackle, Pins		X	X	X				X												X	X								X	X	X	
Suspension - Suspension Bushings		X	X	X				X												X	X								X	X	X	
Suspension - Torque Rods		X	X	X				X												X	X								X	X	X	
Suspension - Tracking Rods, Brackets		X	X	X				X												X	X								X	X	X	
Suspension - U-Bolts, U-Bolt Saddles		X	X	X				X												X	X								X	X	X	
Switches		X	X	X				X												X	X								X	X	X	
Throttle Linage, Cable		X	X	X				X												X	X								X	X	X	
Transfer Case									X											X	X								X	X	X	
Transmission - Non-PACCAR Automated									X											X	X								X	X	X	
Transmission - Non-PACCAR Automatic									X											X	X								X	X	X	
Transmission - Non-PACCAR Manual									X											X	X								X	X	X	
Transmission - PACCAR Branded										X																						
Transmission ***Only Failures Which Trigger Mill***		X	X	X				X												X	X								X	X	X	
Transmission Oil Cooler (Vehicle Mounted)																																
Turbocharger		X	X	X				X												X	X								X	X	X	
Turbocharger - Actuator Coolant Return Line		X	X	X				X												X	X								X	X	X	
Turbocharger - Actuator Coolant Supply Line		X	X	X				X												X	X								X	X	X	
Turbocharger - Coolant Lines		X	X	X				X												X	X								X	X	X	
Turbocharger - Variable Geometry (VGT) Assembly		X	X	X				X												X	X								X	X	X	
Turbocharger Piping, Clamp, Gaskets to Inlet of SCR		X	X	X				X												X	X								X	X	X	
Upholstery (Excludes Wear/Tear Including Soft Trim)		X	X	X				X												X	X								X	X	X	
Valve Train - Camshaft, Bushings		X	X	X				X												X	X								X	X	X	
Valve Train - Cover		X	X	X				X												X	X								X	X	X	
Valve Train - Engine Brake Assembly		X	X	X				X												X	X								X	X	X	
Valve Train - Intake, Exhaust Valves		X	X	X				X												X	X								X	X	X	
Valve Train - Push Rods		X	X	X				X												X	X								X	X	X	
Valve Train - Rocker, Follower Assemblies		X	X	X				X												X	X								X	X	X	
Valve, All Valves		X	X	X				X												X	X								X	X	X	
Vent - Fresh Air		X	X	X				X												X	X								X	X	X	
Visor		X	X	X				X												X	X								X	X	X	
Water Pump		X	X	X				X												X	X								X	X	X	
Water Pump - Cartridge		X	X	X				X												X	X								X	X	X	
Water Pump - Housing		X	X	X				X												X	X								X	X	X	
Weather Seal/Stripping (Excludes Wear/Tear)		X	X	X				X												X	X								X	X	X	
Wheel Bearing (Excludes Wear/Tear)		X	X	X				X												X	X								X	X	X	
Window Defroster Fan		X	X	X				X												X	X								X	X	X	
Window Regulator		X	X	X				X												X	X								X	X	X	
Windshield Washer Pump		X	X	X				X												X	X								X	X	X	
Windshield Washer Reservoir		X	X	X				X												X	X								X	X	X	

Peterbilt 2023 Warranty Reference Guide

Part Description	Emissions Base Warranty	Standard Class 8 Vehicle (Basic Vehicle)	Standard Class 6/7 Vehicle (Basic Vehicle)	Battery Electric (Basic Vehicle)	Standard MX Engine (Base Engine)	Standard Major Engine Components	Standard Major Vehicle Components	Standard Severe Service	Standard PACCAR Alternator & Starter	Standard PACCAR Front Axles	Standard Non-PACCAR Front Axles	Standard PACCAR Clutch	Standard PACCAR Transmission	Standard Non-PACCAR	Standard Frame, Rails, Gussets, Crossmembers, Cab/Hood/Sleeper Corrosion or Perforation Caused by Corrosion	Standard Paint	Extended Warranty: MX Premium	Extended Warranty: MX PP1	Extended Warranty: MX PP2	Extended Warranty: MX Aftertreatment	Extended Warranty: Basic Vehicle	Extended Warranty: Battery Electric Basic Vehicle	Extended Warranty: Major Engine Components	Extended Warranty: HVAC	Extended Warranty: Electrical Wiring Harness Class 8	Extended Warranty: Electrical Wiring Harness Class 6/7	Extended Warranty: PACCAR Clutch	Extended Warranty: PACCAR Transmission	Red Oval Vehicle	Red Oval Engine	Red Oval 90 Day
Windshield Wiper Arm (Excludes Wiper Blade)		X	X	X				X													X								X		X
Windshield Wiper Motor, Control Valve		X	X	X				X													X								X		X
Wiring Harness - ABS Electronic Stability Control Harness, Connectors		X	X	X				X													X								X		X
Wiring Harness - Aftertreatment Mounted Harnesses, Connectors		X	X	X				X													X								X		X
Wiring Harness - Chassis to Aftertreatment Harness, Connectors		X	X	X				X													X								X		X
Wiring Harness - Chassis to Engine Harness, Connectors (Chassis mounted h		X	X	X				X													X								X		X
Wiring Harness - ECU, Connectors		X	X	X				X													X								X		X
Wiring Harness - Engine Mounted Harnesses, Connectors		X	X	X				X													X								X		X
Wiring Harness - Gauges, Connectors		X	X	X				X													X								X		X
Wiring Harness - Other, Connectors		X	X	X				X													X								X		X
Wiring Harness - Transmission, Connectors		X	X	X				X													X								X		X